

## **Generic Classroom – Using a Laptop Computer**

Connect laptop computer to podium HDMI (USB) or VGA, depending upon the connections available. (If VGA on laptop a VGA to HDMI adapter will be required. The podiums after latest update no longer have VGA connectors.)

Turn on the Crestron control panel by pressing the “Power On” button. The power light will blink repeatedly, and the projector will start.

Turn on the laptop computer.

The Crestron control panel will automatically detect and select the active input. There is no need to select the input from the control panel, i.e., HDMI, VGA.

When finished, shut down the laptop.

Press the “Power Off” button on the Crestron control panel.

Disconnect the HDMI (USB), VGA connector (and adapter if used).