

Wham 105 – Using a Laptop Computer

- Connect laptop computer to HDMI cable on podium.
- Power on Crestron control panel.
- Drag laptop icon to “Widescreen” area on Crestron display.
 - Laptop display image will appear on the projector screen.
- Unplug wireless microphone if connected to charger.
- Turn microphone power switch to “On.”
- Wireless microphone and wall mounted speakers may now be utilized for presentation.
- Adjust volume control slider on Crestron control panel display as needed.
- When finished, turn off Crestron control panel and disconnect laptop computer from HDMI connector.