

Wham 228 – Using a Laptop Computer

On laptop, press Ctrl and F8 to select output display. Select “Duplicate” from the available options.

Plug HDMI cable into laptop computer.

On the Crestron control panel:

Turn touchpad on. Projector screens will extend to operating position.

Select “Presentation,” on the left-hand menu.

Drag and drop “Laptop” to left projector screen (and to the right if the image is to be displayed on both.)

If the desktop PC will be used in the podium, select “PC Primary” instead of “Laptop.”

When finished, shutdown Creston control, projector screens will retract. to stored position.